



**655 SOUTH LINCOLN AVE / SAN BERNARDINO CA. 92408**

PHONE 877-470-2975

Web address: [globalwest.net](http://globalwest.net)

**1986 And Up Mustang  
Standard Rack & Pinion Bushing  
RB-3**

**Installation Instructions**

1. The rack and pinion assembly does not have to be removed for installation of this kit. Remove the two bolts, which hold the rack to the frame. Shifting your attention to the steering coupler, remove the bolt and pull the steering shaft from the coupler.
2. Remove the old rubber bushings from the rack. Clean any dirt, rust or corrosion found in the holes of the rack housing.
3. The new rack bushings are all the same size. Install them into the rack housing now. First, position two bushings on the rear of the rack, one on each side. Install them on the crossmember pins first, then put the rack up into place. Install the remaining two bushings into the front of the rack. As you tap on the front two bushings, all bushings will into the rack housing.
4. Re-connect the steering coupler. Torque the bolts down to factory specifications.

