



655 South Lincoln Ave San Bernardino Ca. 92408
PHONE 909-890-0759 / FAX 909-890-0703
Web address: globalwest.net

Part #RB-4
Rack and Pinion Bushings for Lowered Cars

To install offset rack bushings on 1979 to 1985 vehicles:

1. Unfasten the single bolt at the steering coupler and disconnect at the rack and pinion unit.
2. Unfasten the two bolts attaching the rack to the crossmember.
3. Remove the original bushings from the rack.
4. For the 79-85 vehicles, the rack bushings have offset holes that fit the crossmember. Simply line up the holes to lift the rack as high as possible toward the engine.
5. The rack bushings in your kit install into the rack housing from the front of the vehicle. A rubber hammer may assist you in installing the bushings into the rack housing.
6. Line up the rack and slide it into position. As the rack moves into position, re-install the steering coupler. (slight tapping with your rubber mallet may be required) Install the factory bolts & torque to 110 ft. lbs. Retorque the steering coupler bolt.

