



655 South Lincoln Ave San Bernardino Ca. 92408

Toll Free 877-470-2975

[www.globalwest.net](http://www.globalwest.net)

**Part # TS--72T** ---- Replacement for the TS-70  
1967-70 Mustang wheel side fender support  
and bump stop.

The kit includes the following:

- Driver side mount
- Passenger side mount
- (12) 5/16 X 3/4 FLANGE BOLTS
- (12) FLANGE LOCK NUTS
- (2) Bump stops already installed



1. Jack the front of the car up and support it with jack stands.
2. Unbolt the wheel side tower support. You should take the wheel off for easier installation.
3. Install the new inner tower supports. There is a driver and passenger side. The bolt pattern will only allow you to install the supports one way. You cannot get it wrong.
4. Install all six bolts and nuts in the support loosely. Place the head of the bolt in the engine compartment side. Tighten down the top 2 bolts first. Note: When tightening, push the support upward as you tighten. Then move from the top down on the bracket. Tighten to 25 pounds.