



Global West Suspension
655 South Lincoln Ave. San Bernardino, CA. 92408
PHONE: 877-470-2975 FAX: 909-890-0703
globalwest.net

Part # TBC-99 --- 1959-64 Impala Rear upper control arm (quite ride series) – Adjustable TBC-99 allows you to set pinion angle without shims or removing the arm off the car. This arm is mainly used with Ford 9-inch rear ends.

The following items are supplied in the kit:

- Fully assembled upper control arm
- 2—5/8 x 4 x 18 bolts
- 4 --- 16mm flat washers
- 2 --- 5/8 x 18 lock nuts



Installation requires supporting the car on the frame and supporting the rear end.

1. After the car is supported properly, unbolt the upper control arm from the frame bracket and rear end.



2. Install the new upper control arm with new hardware on the rear end side first. Install the new bolt with a flat washer against the head of the bolt and one against the lock nut. Tighten the bolt down till it contacts the bracket. Do not torque the bolt yet.



3. Install the other side of the control arm in the frame bracket. Make sure there are gold bearing spacers on each side of the spherical bearing. The factory installs the spacers. Swing the arm into position and using new hardware, install the bolt with a flat washer against the head of the bolt and one against the lock nut. Torque the bolt to 80 foot-pounds bearing side only, not on the rear end side. Note: The bearing used is a self-lubricating bearing. Do not lubricate it.



4. Next support the vehicle on jack stands under the rear end only and not the frame. Torque the bolt on the rear end side only after the car is resting on the suspension at ride height. Torque to 80 foot-pounds.
5. Check pinion angle: The pinion angle should be set with the vehicle at ride height on a drive on ramp. Measure the angle between the rear end and drive shaft. We recommend 2 to 3 degrees nose down. To adjust the angle, simply loosen the jam nuts on both sides of the adjuster and loosen the set screw on the side of the housing. Place a 9/16 wrench on the adjuster and rotate the adjuster till the pinion angle is set. Next tighten down the jam nut next to the bearing end first while holding the adjuster from turning with the wrench. Then tighten down the jam nut next to the 9/16 wrench. Finally tighten down the set screw and jam nut on the set screw.

Global West also makes the following additional components for 58-64 Impalas:

- Tubular front upper and lower control arms (featuring a major geometry change).
- Front and rear springs (one inch drop)
- Rear tubular lower control arms
- Rear anti-squat bracket
- Rear cross-member supports for strengthening the cross-member from tearing.



- Adjustable track bar/panhard rod.
 - Adjustable track bar relocation kit
- Rear kits above**